

TITLE: Solara ion Fast Fast

Category: Solara ion

Document Number: #110308

Supplied by: Gerber Service

Last Modified: November 3, 2008

Summary: This Solara ion Fast Fact contains the following item:

- Overview of Aftermarket Maintenance products for the Solara ion

Issue: Overview of Aftermarket Maintenance products for the Solara ion

The following items must be kept in inventory by our Solara ion distributors for use by Solara ion customers.

GerberClean Maintenance Solution	P82478B (125ml)	ONLY use to wipe print heads in the 40 hour clean procedure when prompted on Solara ion control panel. (Use every 40 hrs of print time or once a week, whichever comes first.) *Use at other times can cause nozzle loss. Never use GerberClean in place of GerberCAT flush.
GerberCAT Flush Solution	P82137B (bottle 250ml)	Use with Fisher Scientific foam tipped swabs to clean the print heads at the start and end of each day, after 2 hours of idle time and after 4 hours of printing time.
All Purpose wipes	P78454A (pack of 56)	Use in the ink waste tray to absorb excess ink.
Anticon® Gold heavy-weight, clean room wipes	P82244A (300 count)	Use with GerberCAT flush to wipe the print heads in the 40 hour clean procedure. Anticon wipes are the only wipes that should ever touch a swab or the print heads.
Fisher Scientific foam-tipped swabs	P77970A (pack of 50) P82529A (pack of 250) P82528A (pack of 500)	Use for cleaning the print heads. These non-scratching, lint free swabs are the only swabs recommended for the Solara ion print head. *Please be aware that damage caused by use of unapproved swabs will not be covered under the standard 12 month warranty for the Solara ion or Gerber Service Contract.